

DISCREET CARRY CONCEPTS MONOBLOCK GEAR CLIP

INSTALLATION INSTRUCTIONS

1. Remove tuckable clips on your holster.
2. Place both posts into the top two holes of the holster from the inside.
3. Take each washer and put it on top of each post.
4. Place the monoblock clip on top of the washers.
5. Fasten the screws on top of the monoblock clip until tight.



DISCREET CARRY CONCEPTS MONOBLOCK GEAR CLIP

.250"
Screws

.188"
Washers

.250"
Posts

