



⚠ UNLOAD & MAKE WEAPON SAFE ⚠

1. Slide Peak sight onto rail.
2. Insert cross-bolt while applying minimal pressure to avoid cross-threading.
3. Tighten cross-bolt.



MAX TORQUE 25 INCH-LBS



4. Press your thumb against windage dial / Pinch elevation dial with your forefinger and thumb. Turn dials in the direction of the arrow to move point of impact up (UP) or right (R).

MOR PER CLICK $7.5 \div \text{SIGHT RADIUS}$