





B.A.D. Lever[®]

Battery Assist Device




- ⚠ WARNING: BEFORE STARTING, MAKE SURE THE WEAPON IS UNLOADED, THE CHAMBER IS EMPTY, AND THE SAFETY ENGAGED.**
- ⚠ CAUTION: PLEASE READ ALL INSTRUCTIONS BEFORE PROCEEDING. COMPONENTS UNDER SPRING PRESSURE MAY EJECT FORCEFULLY AND COULD CAUSE INJURY.**
- ⚠ WARNING: OBSERVE SAFE FIREARM HANDLING PRACTICES AT ALL TIMES. FAILURE TO DO SO MAY RESULT IN SERIOUS BODILY INJURY OR DEATH. MAGPUL INDUSTRIES SHALL NOT BE RESPONSIBLE FOR INJURY, DEATH OR PROPERTY DAMAGE RESULTING FROM FAULTY INSTALLATION, MISUSE, ILLEGAL USE, OR MODIFICATION OF THIS PRODUCT.**

INCLUDED PARTS




B.A.D. LEVER INSTRUCTIONS



STEP 1: INSTALL B.A.D. LEVER

On the receiver, lift the *Bolt Catch* and place the *B.A.D. Lever Back Plate* (1) under the *Bolt Catch*. Place the *B.A.D. Lever* (2) on top of the *Bolt Catch*, lining up the screw hole with the *Back Plate's* threaded hole.



STEP 2: TIGHTEN SCREW

Using the provided *T8 Torx Wrench* (4), hand tighten the *T8 Screw* (3). Be careful to not overtighten. Overtightening may result in damage to the *B.A.D. Lever* assembly.

Perform final inspection including function check per *US Army TM 9-1005-319-23&P Unit and Direct Support Maintenance Manual (3-97)* to verify proper weapon function.


Always test fire your weapon before using it in an operational environment.

B.A.D. LEVER USAGE INSTRUCTIONS

LOCK BOLT CARRIER


Make sure weapon safety is engaged and weapon is pointed in a safe direction.

To lock the *bolt carrier group* to the rear, place your finger under the paddle of the *B.A.D. Lever*, taking care not to enter the trigger well. Apply upward pressure while pulling the *charging handle* back until the *bolt catch* engages the bolt face.



RELEASE BOLT CATCH

To release the *bolt catch* place your finger on top of the paddle and press down taking care to keep finger out of the trigger well.



USING THE BOLT CATCH

The *B.A.D. Lever* allows the *bolt catch* to be released in the standard "ping pong paddle" fashion. Press the ribbed upper surface in toward the weapon as usual to release the *bolt catch*.

- ⚠ Proper installation and use modifies the weapon and its operational procedures. Verify proper installation and practice use extensively before entering a tactical or other live fire situation. Failure to do so may result in serious injury or death of the user or another.**